


7.2/3 Rear Shock Damper – Exploded View / Parts List




No	QTY.	Part #	Description
1	1	90170	Knob, Adjuster
2	1	90171	Bolt, Shaft
3	1	90172	Top Cap
4	1	90117	Bottom Bumper
5	1	90173	ML7.2 Tube, Inner
6	1	90174	ML7.2 Rod, Adjuster
7	1	90175	ML7.2 Damper Shaft
8	1	90176	Seal Head
9	1	90032	DU Bushing 10 X 12 X 6
10	1	90196	Collar, Neg Spring
11	1	90177	Spring, Negative

No	QTY.	Part #	Description
12	1	90101	Bumper, Top-out
13	1	90179	Collar, Top-Out
14	1	90180	Spring, CheckValve
15	1	90181	Shim - 10.6 X 17.8 X .25
16	1	90182	Glide Ring
17	1	90183	Piston, Damper
18	2	90034	Shim - 8 X 16 X.15
19	1	90184	Bolt, Piston
20	1	90185	ML7.2 Damper Tube
21	1	90186	Piston, Floating
22	1	90187	ML7.2 Attachment Boss

No	QTY.	Part #	Description
23	1	90188	Membrane, Nitro
24	1	90189	SetScrew, Nitro
25	1	90190	O-Ring 1.0 X 21
26	2	90191	O-Ring 1.5 X 4
27	1	90192	O-Ring 1.5 X 18
28	1	90193	O-Ring 1.5 X 12
29	1	90011	O-Ring 2.0 X 10
30	1	90194	O-Ring 2.0 X 16
31	1	90195	O-Ring 2.0 X 27
32	1	90209	O-Ring 3.0 X 10

8.0 Rear Shock Damper – Exploded View / Parts List



Item	Qty	Part #	Description
1	1	90170	Knob, Adjuster
2	1	90171	Bolt, Shaft
3	1	90172	Top Cap
4	1	90117	DUC32 Bottom Bumper
5	1	90211	ML8 Tube, Inner
6	1	90212	ML8 Rod, Adjuster
7	1	90213	ML8 Damper Shaft
9	1	90176	Seal Head
10	1	90032	DU Bushing 10 X 12 X 6
11	1	90196	Collar, Neg Spring
12	1	90177	Spring, Negative

Item	Qty	Part #	Description
13	1	90179	Collar, Top-Out
14	1	90180	Spring, CheckValve
15	1	90182	Glide Ring
16	1	90183	Piston, Damper
17	1	90184	Bolt, Piston
18	1	90221	ML8 Damper Tube
19	1	90186	Piston, Floating
20	1	90214	ML8 Spring Guide
21	1	90215	ML8 Spring, Main
22	1	90216	ML8 Attachment Boss

Item	Qty	Part #	Description
23	2	90034	Shim - 8 X 16 X .15
24	1	90181	Shim - 10.6 X 17.8 X .25
26	1	90190	O-Ring 1.0 X 21
27	2	90191	O-Ring 1.5 X 4
28	1	90192	O-Ring 1.5 X 18
29	1	90193	O-Ring 1.5 X 12
30	1	90217	O-Ring 2.0 X 9
32	1	90194	O-Ring 2.0 X 16
33	1	90195	O-Ring 2.0 X 27
34	1	90209	O-Ring 3.0 X 10